Errata 1

Manual: 19943, 19942

Manual Index: 0100

Table of Contents:

1. Reference: Page: 3-3, Chapter 3 Configuration ..... 1 - 3

© PEP Modular Computers GmbH

This page was intentionally left blank.

1. Reference: Page: 3-3, Chapter 3 Configuration



Note:

When installing and configuring the PMCP251 for operation always ensure that it is installed in a bus-master slot, otherwise improper operation will result.

Please refer to the appropriate system documentation for a description of bus-master slots.

© PEP Modular Computers GmbH

This page was intentionally left blank.