Errata 3

Manual: 26037

Manual Index: 01

Table of Contents:

1. Reference: Page 5-13, Chapter 5.7 ..... 3 - 3

This page has been intentionally left blank.

1. Reference: Page 5-13, Chapter 5.7

The referenced information is revised as follows:

The following NetBootLoader command is added:

SPEED

FUNCTION:	Enables or disables fast booting
SYNTAX:	**speed [<switch>]** where: speed command <switch> parameter: numeric string 0, 1 when set to 0 (zero) disables “fast” boot mode when set to 1 (one) enables “fast” boot mode when not specified, displays current setting
DESCRIPTION:	This command is used to specify to the NetBootLoader that either the complete booting process is to be performed or that a shortened boot process is to be performed.
USAGE:	Enable “fast” booting COMMAND / RESPONSE: **NetBtLd> speed 1**
	Display the current setting COMMAND / RESPONSE: **NetBtLd> speed** **Speed mode : "fast" boot up process.**

This page has been intentionally left blank.