Errata 1

Manual: 33274

Manual Index: 4.0

Table of Contents:

1. Reference: Page 2 - 20, Chapter 2.3.12, Table 2-18 ..... 1 - 3

This page has been intentionally left blank.

1. Reference: Page 2 - 20, Chapter 2.3.12, Table 2-18

The referenced information (table) is revised as follows.

The Table 2-18:

Table 2-18: SATA Extension Connector J23 Pinout

PIN	SIGNAL	FUNCTION	I/O
1	SATA_RX1-	Differential Receive -	I
2	GND	Ground signal	--
3	SATA_RX1+	Differential Receive +	I
4	GND	Ground signal	--
5	GND	Ground signal	--
6	5V	5V power	--
7	SATA_TX1-	Differential Transmit -	O
8	GND	Ground signal	--
9	SATA_TX1+	Differential Transmit +	O
10	GND	Ground signal	--
11	GND	Ground signal	--
12	5V	5V power	--

is changed to read:

Table 2-18: SATA Extension Connector J23 Pinout

PIN	SIGNAL	FUNCTION	I/O
1	SATA_RX-	Differential Receive -	I
2	GND	Ground signal	--
3	SATA_RX+	Differential Receive +	I
4	GND	Ground signal	--
5	GND	Ground signal	--
6	5V	5V power	--
7	SATA_TX-	Differential Transmit -	O
8	GND	Ground signal	--
9	SATA_TX+	Differential Transmit +	O
10	GND	Ground signal	--
11	GND	Ground signal	--
12	5V	5V power	--

This page has been intentionally left blank.