Errata 1

Manual: 21846

Manual Index: 04

Table of Contents:

1. Reference: Page 2-11, Chapter 2.3.3, Table 2-5……..……..1-3
2. Reference: Page 4-4, Chapter 4.1.3, Table 4-2……..1-3
3. Reference: Page 4-4, Chapter 4.1.3, Table 4-3……1-3
4. Reference: Page 4-13, Chapter 4.3.8, Table 4-12……..1-3

 © 2005 Kontron Modular Computers GmbH

This page has been intentionally left blank.

© 2005 Kontron Modular Computers GmbH

1. Reference: Page 2-11, Chapter 2.3.3, Table 2-5

The referenced information (table) is revised as follows.

Signal naming RS-485, Full-Duplex, Pin 4: -TxD **is changed to read:** +TxD
Signal naming RS-485, Full-Duplex, Pin 7: +TxD **is changed to read:** -TxD

2. Reference: Page 4-4, Chapter 4.1.3, Table 4-2

The referenced information (table) is revised as follows.

The following columns are added:

	R23	R21
Flash/DiskOnChip (default):	Set	Open
NVSRAM:	Open	Set
4 Mbit EPROM:	Set	Open

3. Reference: Page 4-4, Chapter 4.1.3, Table 4-3

The referenced information (table) is revised as follows.

The following columns are added:

	R16	R18
Flash/DiskOnChip (default):	Set	Open
NVSRAM:	Open	Set
4 Mbit EPROM:	Set	Open

4. Reference: Page 4-13, Chapter 4.3.8, Table 4-12

The referenced information (table) is revised as follows.

Content of bit 6:	res.	**is changed to read:**	SER_ECHO
Default setting for bit 6:	n/a	**is changed to read:**	0
Name of bit 6:	res.	**is changed to read:**	SER_ECHO
Description for VAL 0:	reserved	**is changed to read:**	Echo off (RS-485)
Description for VAL 1:	reserved	**is changed to read:**	Echo on (RS-485).

© 2005 Kontron Modular Computers GmbH

This page has been intentionally left blank.

© 2005 Kontron Modular Computers GmbH